

GXP1625



GRANDSTREAM
GXP-1625

1.Default User = admin , Password = admin

The login interface for the Grandstream GXP1625. It features a dark blue background with the Grandstream logo and tagline 'CONNECTING THE WORLD' in the top left, and the model number 'GXP1625' in the top right. A central white box contains the login form with three fields: 'Username' with 'admin' entered, 'Password' with six dots, and 'Language' with 'English' selected in a dropdown menu. A blue 'Login' button is positioned to the right of the password field.

GRANDSTREAM
CONNECTING THE WORLD

GXP1625

Username

Password

Language ▼

2. เข้า Account เพื่อ Set Sip Account

Grandstream GXP1625 Admin Logout | Reboot | Factory Reset | English

GRANDSTREAM
CONNECTING THE WORLD

STATUS ACCOUNTS **S** MAINTENANCE PHONEBOOK

Account 1
Account 2

General Settings
Network Settings
SIP Settings
Audio Settings
Call Settings
Intercom Settings
Feature Codes

Version 1.0.4.106

Accounts

Account 1

General Settings

Network Settings
SIP Settings
Audio Settings
Call Settings
Intercom Settings
Feature Codes
Account 2

General Settings

Account Active No Yes

Account Name

SIP Server

Secondary SIP Server

Outbound Proxy

Backup Outbound Proxy

BLF Server

SIP User ID

Authenticate ID

Authenticate Password

Name

Voice Mail Access Number

Account Display User Name User ID

3.Set Audio codecs 1 PCMA , G.729

Grandstream GXP1625 Admin Logout | Reboot | Factory Reset English ▼

GRANDSTREAM
CONNECTING THE WORLD

STATUS ACCOUNTS SETTINGS NETWORK MAINTENANCE PHONEBOOK

Version 1.0.4.108

Accounts

- Account 1
- General Settings
- Network Settings
- SIP Settings
- Audio Settings**
- Call Settings
- Intercom Settings
- Feature Codes
- Account 2

Audio Settings

Send DTMF in-audio via RTP (RFC2833) via SIP INFO

DTMF Payload Type

Preferred Vocoder - choice 1

Preferred Vocoder - choice 2

Preferred Vocoder - choice 3

Preferred Vocoder - choice 4

Preferred Vocoder - choice 5

Preferred Vocoder - choice 6

Preferred Vocoder - choice 7

Use First Matching Vocoder in 200OK SDP No Yes

Disable Multiple m line in SDP No Yes

SRTP Mode

Symmetric RTP No Yes

Silence Suppression No Yes

Voice Frames per TX

G723 Rate 6.3kbps encoding rate 5.3kbps encoding rate

G.728-32 Packing Mode ITU IETF

iLBC Frame Size 20ms 30ms

iLBC Payload Type

Jitter Buffer Type

Jitter Buffer Length

Hide Vocoder No Yes

4.แก้ไข IP Phone Grandstream ตั้งเอง

The screenshot displays the Grandstream GXP1625 web interface. At the top, there is a navigation bar with 'Grandstream GXP1625' on the left and 'Admin Logout | Reboot | Factory Reset | English' on the right. Below this is the Grandstream logo and a main navigation menu with 'STATUS', 'ACCOUNTS', 'SETTINGS', 'NETWORK', 'MAINTENANCE', and 'PHONEBOOK'. The 'ACCOUNTS' menu is expanded, showing 'Account 1' and 'Account 2'. The 'SETTINGS' menu is also expanded, showing 'General Settings', 'Network Settings', 'SIP Settings', 'Audio Settings', 'Call Settings', 'Intercom Settings', and 'Feature Codes'. The 'SIP Settings' menu is further expanded, showing 'Basic Settings', 'Custom SIP Headers', 'Advanced Features', 'Session Timer', and 'Security Settings'. The 'Security Settings' page is active, showing a list of settings for 'Account 1'. The settings are: 'Check Domain Certificates' (No selected), 'Validate Certificate Chain' (No selected), 'Validate Incoming Messages' (Yes selected), 'Check SIP User ID for Incoming INVITE' (Yes selected), 'Accept Incoming SIP from Proxy Only' (Yes selected), and 'Authenticate Incoming INVITE' (No selected). At the bottom of the settings list are three buttons: 'Save', 'Save and Apply', and 'Reset'. The version number 'Version 1.0.4.106' is visible in the top right corner of the main content area.

Grandstream GXP1625 Admin Logout | Reboot | Factory Reset English

GRANDSTREAM CONNECTING THE WORLD

STATUS ACCOUNTS SETTINGS NETWORK MAINTENANCE PHONEBOOK

Account 1 Account 2

General Settings Network Settings SIP Settings Audio Settings Call Settings Intercom Settings Feature Codes

Basic Settings Custom SIP Headers Advanced Features Session Timer Security Settings

Version 1.0.4.106

Accounts

Account 1

General Settings Network Settings SIP Settings

Basic Settings Custom SIP Headers Advanced Features Session Timer

Security Settings

Audio Settings Call Settings Intercom Settings Feature Codes

Security Settings

Check Domain Certificates No Yes

Validate Certificate Chain No Yes

Validate Incoming Messages No Yes

Check SIP User ID for Incoming INVITE No Yes

Accept Incoming SIP from Proxy Only No Yes

Authenticate Incoming INVITE No Yes

Save Save and Apply Reset